

The Garden Water Fountain Company  
www.garden-water-fountains.com  
860-642-7790

**Assembly and Instructions:** For complete online instructions see  
www.oraclefountains.com

Check for any damage that may have occurred during shipping. If any damage to the fountain is noticed during unpacking, please call our customer service department immediately.

Congratulations on the purchase of your new *VIGAN* fountain.

**WARNING: As with any fountain there is a risk of water damage due to splashing or leakage. Do not place fountain where it could cause damage to furniture or other items. Splashing can occur on start up.**

**Assembly:**

- Vigan fountain should be assembled where it is going to be used.
- Route pump cord through tube in bottom of pot making sure to place cord cap onto cord tube.
- Attach hose to pump and bottom of upper bowl
- Position upper bowl so that water will flow to one side and spill into pot.
- There is a metal locating pin on the upper bowl that indexes into a hole on the large urn lip.
- The small moon rocks pebbles can be arranged in any manner desired.

**Start Up:**

- Start by filling the pot enough to cover the pump (NEVER LET PUMP RUN DRY).
- Plug pump in and adjust flow with valve on pump if necessary.

**Maintenance:**

- To keep fountain clean of algae and bacteria add 1 teaspoon of bleach every 4 to 5 days. To avoid damage to pump and components do not add more bleach than is recommended.
- If you notice air bubbles coming from the pump you probably need to add more water.
- To remove any hard water spots use a light vinegar solution or common household scale remover.

**Warranty** is limited to repair or replacement of product, at Ecosphere's option. Ecosphere is not liable for any consequential damages. Warranty period is six months on pumps, and one year on other parts. No warranty on breakage. Warranty void if pump is run without water. Defective pumps in warranty must be returned to Ecosphere by US mail and if found defective will be replaced free of charge. **All** fountain returns require a RA # and must be shipped prepaid. Any product returned without an RA # will not be accepted. Any questions can be directed to our customer service department at 1-800-729-9870. 0803

# VIGAN ASSEMBLY

