

Assembly and Instructions for **ST Series** Fountains

Congratulations on the purchase of your new *Stone Pillar Oracle* Fountain.

Check for any damage that may have occurred during shipping. If any damage to fountain is noticed during unpacking, keep packing and notify the carrier immediately for inspection.

WARNING: As with any fountain there is a risk of water damage due to splashing. Do not place fountain where it could cause damage to furniture or other items. Splashing can occur on start up.

Your Oracle Fountain™

Your Stone Pillar fountain is for either indoor or outdoor use. Because of the irregularities in the sphere there may be some splashing during operation.

Assembly:

- Feed the cord through the cord tube. Place the cord cap securely over the cord tube. This will prevent water from running down the cord tube.
- Attach the hose securely to the motor output.

Start Up:

- Start by filling the reservoir at least half full. Place the pump in the water and verify that it pumps water.
- Place the sphere on the base and adjust it so that it is centered.
- You can minimize the amount of splashing on startup if you first wet the sphere with a spray bottle. If the sphere is wet the water will "stick" to the sphere.
- Each pump has a flow control valve that you can use to adjust the amount of water flowing over the sphere.

Maintenance:

- Add water as necessary.
- To keep sphere clean of algae and bacteria add 1 teaspoon of bleach every 4 to 5 days. To avoid damage to pump and components do not add more bleach than is recommended.
- If you notice air bubbles coming from the pump you probably need to add more water.
- To remove any hard water spots use a light vinegar solution or common household scale remover.

Warranty is limited to repair or replacement of product, at Ecosphere's option. Ecosphere is not liable for any consequential damages. Warranty period is six months on pumps and one year on other parts. No warranty on breakage. Warranty void if pump is run without water. Defective pumps must be returned to us U.S. Mail and if found defective will be replaced free of charge and postage credited. Fountain returns require a RA# and must be shipped prepaid. Any questions can be directed to our customer service department at 1-800-729-9870.